


ASSEMBLY INSTRUCTIONS

DESK RETURN SCREEN



*Images reflect typical hardware options. Please refer to packing list for items & quantities specific to your order


Thank you for your order!

For questions or concerns regarding your order or installation, please contact customer service via email at customercare@ezobord.co.uk, or call us at 01843 666111 (International +44 1843 666111).


Visit our website at shop.ezobord.com/uk

ASSEMBLY INSTRUCTIONS

DESK RETURN SCREEN



EZOBORD SCREEN **X2**



PJ-3 BRACKET **X2**
(LEFT HALF X1 / RIGHT HALF X1 / BOLT X1 /
PLASTIC COVER X2)

Thank you for your order!



For questions or concerns regarding your order or installation, please contact customer service via email at customercare@ezobord.co.uk, or call us at 01843 666111 (International +44 1843 666111).

Visit our website at shop.ezobord.com/uk

ASSEMBLY INSTRUCTIONS

DESK RETURN SCREEN

- 1** Screw the right half of PJ3 BRACKET onto the desktop.
(*Screws, hand drill not included.)



- 2** Put the PLASTIC COVER of the PJ3 onto the fixed half

Thank you for your order!


For questions or concerns regarding your order or installation, please contact customer service via email at customercare@ezobord.co.uk, or call us at 01843 666111 (International +44 1843 666111).

Visit our website at shop.ezobord.com/uk

ASSEMBLY INSTRUCTIONS

DESK RETURN SCREEN

- 3** Clamp the EZOBORD SCREEN with the LEFT HALF covered by the PLASTIC COVER of the P33. TIGHTEN the bolt with Allen key.
(*Allen key not included.)



Thank you for your order!

For questions or concerns regarding your order or installation, please contact customer service via email at customercare@ezobord.co.uk, or call us at 01843 666111 (International +44 1843 666111).

Visit our website at shop.ezobord.com/uk