


ASSEMBLY INSTRUCTIONS

WORK ZONE DIVIDERS



*Images reflect typical hardware options. Please refer to packing list for items & quantities specific to your order

RECOMMENDED TOOLS

Drill - Level - Allen Key 3/32 - Allen Key 2.5 - Tape Measure - Wire Cutter

Thank you for your order!


For questions or concerns regarding your order or installation, please contact customer service via email at customercare@ezobord.co.uk, or call us at 01843 666111 (International +44 1843 666111). Visit our website at shop.ezobord.com/uk




ASSEMBLY INSTRUCTIONS

WORK ZONE DIVIDERS

- Locate available suspension points on ceiling in relation to work zone divider suspension locations
- Mount brass locators securely onto ceiling with substrate appropriate fasteners (not included)
- Thread Upper Suspension Housing onto brass locator by hand only
- 4 Determine suspension points on WZD





- Mark and drill pilot hole on WZD
- Attach adjustable combination clamp to the WZD in predetermined location usingthe set screw supplied with clamp

Thank you for your order!


For questions or concerns regarding your order or installation, please contact customer service via email at customercare@ezobord.co.uk, or call us at 01843 666111 (International +44 1843 666111). Visit our website at shop.ezobord.com/uk



ASSEMBLY INSTRUCTIONS

WORK ZONE DIVIDERS

Attach the CVD Clamps between the top panel and bottom panel using the set screw supplied with CVD Clamps



- Raise unit to desired height by depressing Ezo Clamp top nozzle and threading cable through from top (Ezo Clamp will lock when nozzle is released)
- 9 Hand tighten top nozzle and trimexcess cable

Thank you for your order!

For questions or concerns regarding your order or installation, please contact customer service via email at customercare@ezobord.co.uk, or call us at 01843 666111 (International +44 1843 666111). Visit our website at shop.ezobord.com/uk